

PLUMBITE® PUSH ON FITTINGS

Installation Instructions:

1. For a proper water tight fit, use a deburring tool to remove burrs. Use sand cloth to obtain a smooth edge to pass by rubber seal of fitting without damage. Tube must be round and free of scratches and imperfections.
2. Mark the outside of the pipe at the Install Depth to help ensure proper installation.
3. Remove and discard the included inner plastic stiffener when using the fitting with Copper and CPVC installations. The stiffener is only required when installing PEX and PE-RT tubing. Use disconnect tool (sold separately) to remove stiffener same as if you are removing pipe/tubing.

To Install: While securely holding the fitting, push the pipe/tubing straight into the fitting. Press pipe/tubing until you feel it firmly hit the stop inside the fitting. It will be at the Install Depth mark.

To Remove: Snap removal tool (sold separately) over pipe/tubing. While firmly pressing removal tool against plastic collar at fitting opening, carefully slide pipe/tubing the opposite direction out of the fitting.

Operate at temperatures from 0 to 180°F (82°C) at a maximum working pressure of 200 PSI (1379 kPa).

WARNING: Not designed for underground use, do not bury.

Install Depth/Profundidad para Instalar	
Size	Depth
1/4" (3/8"OD)	11/16" (17mm)
3/8" (1/2"OD)	13/16" (21mm)
1/2" (5/8"OD)	15/16" (24mm)
3/4" (7/8"OD)	1-1/8" (27mm)
1" (1-1/8"OD)	1-3/16" (21mm)
1-1/2" (1-3/8"OD)	1-11/16" (42mm)
2" (2-1/8"OD)	1-3/4" (45mm)

ACCESORIOS DE EMPUJE PLUMBITE®

Instrucciones de instalación:

1. Para lograr un buen ajuste de la tubería de agua, utilice una herramienta para quitar rebabas. Utilice papel de lija para obtener un extremo suave y poder sellar el accesorio con goma sin dañarlo. La tubería debe ser circular y libre de rayones e imperfecciones.
2. Marque la parte externa de la tubería en la siguiente marca de Profundidad para la instalación para poder garantizar una instalación adecuada.
3. Retire y deseche el refuerzo interno de plástico incluido cuando utilice el accesorio con instalaciones de cobre y CPVC. El refuerzo solo se necesita en el caso de instalar tuberías PEX y PE-RT. Utilice una herramienta de desconexión (se vende por separado) para retirar el refuerzo de la misma manera en que retiraría un caño o tubería.

Para la Instalación: Mientras sostiene el accesorio firmemente, introduzca el caño o la tubería directamente en el accesorio. Presione el caño o la tubería hasta sentir que alcanza el cierre dentro del accesorio. Estará en la marca de Profundidad para la instalación.

Para Retirarlo: Acople la herramienta de extracción (se vende por separado) sobre el caño o tubería. Mientras presiona la herramienta de extracción firmemente contra el soporte de plástico en la abertura del accesorio, deslice el caño o la tubería cuidadosamente en sentido contrario fuera del accesorio.

Funciona a temperaturas de 0 a 180° F (82° C) con una presión de operación máxima de 200 PSI (1379 kPa).

ADVERTENCIA: No está diseñado para uso subterráneo, no enterrar.